

# NON-RESIN INSTALLATION TOOL KIT



**A- Goggles (Eye protection whilst drilling)**

**B- ½” Drive 17mm Deep Socket (For fixing hex head coach screws)**

**C- 14mm x 450mm SDS Masonry Drill (For drilling all holes)**

**D- 12” Long Nose Air Gun (For Blowing out drilled holes)**